



Stretch Belt Mate™ Kit



Use for all stretch fit belt applications


- Universal installation and removal of all stretch fit belts
- Easily installs all stretch fit belts
- Allows removal and reuse of stretch fit belts

Installation




Installation tool on pulley


Position belt on accessory drive pulley (i.e. A/C compressor, P/S pump, Alt.)



1. Place installation tool over crankshaft pulleys with belt on leading edge of tool



2. Use a ratchet to turn crankshaft in clockwise direction




3. Guide belt on to pulley and ensure belt ribs are properly aligned


Removal



Removal tool on pulley



1. Position removal tool between pulley and belt as shown



2. Use a ratchet to turn crankshaft in clockwise direction

Belt will be lifted off pulley and slide off tool



PATENT PENDING

Part No: 70990

PRIVATE BRAND TOOLS
(AUSTRALIA) PTY LTD
A.B.N. 72 067 983 475
41 Moreton Street
Heathwood QLD 4110
Australia

Phone: +61 7 3278 8299
Fax: +61 7 3278 8399

Internet: www.pbtusa.com
Email: sales@pbtusa.com